




# KEY SWITCH USER'S GUIDE

## SWITCHES


### Installation

1. Place the mortise cylinder through the 1-3/16" hole in the center of the aluminum faceplate.
2. Mount the cylinder/switch bracket on the reverse side of the faceplate. Make sure that the teeth are positioned inside the grooves along the cylinder. Attach the cylinder nut to fasten.
3. Insert the switch(es) into the 1/2" holes located on the bracket below the cylinder. For ideal installation thread the top nut an 1/8" down and tighten bottom nut using a 9/16" wrench.



## Wiring

1. Make wire connections as shown.
2. Fasten faceplate assembly to electrical box with the tamperproof 6-32 machine screws and spanner hand tool supplied.



**SPDT Wire Connection**

## Specifications

Description	Switch Mode	Switch Configuration	Switch Rating	Standard Finish
960-MO Key Switch	Momentary Action	SPDT N/O & N/C	3A @ 125 VAC/VDC  & CSA 1A @ 250 VAC/VDC  & CSA	28 or 40 28 or 40

**NOTE:** Specifications are subject to change without notice.



Our Service Technicians can be called 24 hours a day, 7 days a week. For more information visit [www.beasensors.com](http://www.beasensors.com).

For email support contact us at: [Tech\\_Services@beainc.com](mailto:Tech_Services@beainc.com)

Phone: 1-800-523-2462

Fax: 1-888-523-2462

After Normal Business Hours

West / Mexico  
1-888-419-2564

Central  
1-800-407-4545

AK, MI, WI,  
TX, Canada  
1-866-836-1863

East  
1-866-249-7937