SARGENT® INSTALLATION INSTRUCTIONS FOR Trans LEVER LOCK with 50 FUNCTION (11G50) CYLINDER

FOR INSTALLATION ASSISTANCE, CONTACT SARGENT AT 800-727-5477

Lock Body Assembly

- 1. Prep door and install lock body and roses according to T-Zone Installation Instructions A7469, steps 1 through 7.
- 2. Assemble cylinder and levers according to following steps.

2 Cylinder Assembly

- 1. Insert parts into cylinder body as shown in illustration.
- Slide spring onto indicator pin. Then insert pin into rear of cylinder body.
- 3. Insert key block-out bar, round end first, into cylinder.
- 4. Slide nylon ring onto back of cylinder.
- 5. TO PREVENT PARTS FROM SLIDING OUT OF CYLINDER BODY, KEEP BODY HORIZONTAL OR END POINTED UP.



3 Lever Installation

Cylinder Removal

1. Remove security screw.

6. Install new cylinder.

- 1. Place cylinder with assembled parts into outside lever.
- 2. Put key into cylinder. Making sure the key block out bar is still within the cylinder, but in the projected position.
- Gently assemble the cylinder and lever onto the outside sleeve. Align the spring in the center and two metal projections at 12 & 6 o'clock with back of cylinder.
- 4. Push cylinder onto outside sleeve and rotate the key **counterclockwise** 45° and hold.
- 5. Push lever onto lock until lever catch button engages hole in lever. Secure with 6 lobe security set screw.



IMPORTANT – Check operation of levers and latch bolt before closing door



ASSA ABLOY, the global leader in door opening solutions

 Insert key and rotate key 45° counterclockwise.
Depress lever catch button and pull lever out approximately 1/4" to clear lever catch.

gently removing lever from sleeve.

indicator pin or key block-out bar.

4. Rotate key 45° clockwise to horizontal and remove key,

5. Remove cylinder from lever being careful not to drop

A7608B

